



Elektralite LED Pro Line Dazer Channel assignments And Menus (Preliminary Release August 2011).

DMX CHANNEL	DETAILS OF FUNCTION
1.Red	0 to 100%
2.Green	0 to 100%
3.Blue	0 to 100%
4.GrandMaster dim	0 to 100% (This needs to be "up" for other channels to work).
5.Strobe	000~128: Adjustable White scale
	129~192: Strobe slow to fast
	193~255: No strobe
6.Effects channel	000~150: Adjustable colors
	151~171: Color strobe
	172~182: Color changing quickly
	183~213: Color changing slowly
	214~234: LED will be off max time and will be sound activated
	235~255: LED will light on max time and will be sound activated
7.Speed channel	0-255: 0 is no speed slow down added. 255 maximum slow down

